

ST71A Prepurge Timer For R4795 Primary Control System

INSTALLATION INSTRUCTIONS

APPLICATION

The ST71A is a plug-in timer which provides a 7, 10, 30, 60, or 90 second fixed prepurge timer period at the start of each R4795 cycle.

INSTALLATION



CAUTION

Disconnect power supply before connecting to prevent electrical shock or equipment damage.

1. Make sure timer has the correct timing period.
2. Locate guide slots in metal bracket of R4795. (See Fig. 1.) Fit timer through slots and push downward. Be sure to match connectors to 4 metal prongs.
3. Attach gummed label near timer (See Fig. 1.) for future identification.




Fig. 1. Location of ST71A Timer and Label for R4795 Primary Control.

Automation and Control Solutions

Honeywell International Inc.
1985 Douglas Drive North
Golden Valley, MN 55422
customer.honeywell.com

Honeywell Limited-Honeywell Limitée
35 Dynamic Drive
Toronto, Ontario M1V 4Z9

© U.S. Registered Trademark
© 2008 Honeywell International Inc.
60-0148-1 M.S. 04-08



Printed in U.S.A. on recycled paper containing at least 10% post-consumer paper fibers.



60-0148-1